

## FORK SPRING APPLICATION LIST

MAKE	MODEL	YEAR	IKON Nr	SPACER /COMMENT
	<b>ATK</b>			
ATK	WHITE POWER 4054	ALL		
ATK	WHITE POWER SUPER ADJUST	ALL	500-078	25% HEAVIER
	<b>APIRILIA</b>			
APRILIA	RS250 Single fork spring model	95-97	500-042	
APRILIA	RS250 LD A1	98on	500-135	
APRILIA	MOTO6.5	92-96	500-085	
APRILIA	PEGASO650(KAYABA)DIA.41 USD	96<	500-130	
APRILIA	PEGASO650(MARZOCI)40MM USD	96on	500-131	
APRILIA	ETV 1000 Caponord ZD4PS	02-	500-284	
APRILIA	RSV 1000 Mille ZD4	98 on	500-240	
APRILIA	SL1000 Falco	00 on	500-240	
	<b>BIMOTA</b>			
BIMOTA	DB2 (PAIOLI)		500-022	
BIMOTA	KB2 Fi 40 Race		500-232	
BIMOTA	SB6 (PAIOLI + 20MM HULSE)	94on	500-139	
BIMOTA	YB4 (42M1R)		500-207	
BIMOTA	YB5		500-207	
BIMOTA	YB6/8 (42M1R)		500-207	
BIMOTA	YB8 DIECI (USD)	91on	500-018	
BIMOTA	YB9 SR (41MM PAIOLI RSU)	94on	500-022	
BIMOTA	YB9 SRI (43MM PAIOLI RSU)	94on	500-089	
	<b>BMW</b>			
BMW	R45	78-85	500-140	
BMW	R50/5	upto 87	500-084	
BMW	R60, R60/5	upto 87	500-084	
BMW	F650	94-00	500-141	250MM X 34
BMW	F650GS	00 on	500-141	
BMW	F650GS Dakar	00 on	500-255	
BMW	F650CS	02 on	500-282	
BMW	R65	78-84	500-140	NONE, Can also use 500-083 with 15mm spacer. 500-083 good for heavier duty use.
BMW	R65LS	78-85	500-140	
BMW	R65 (30MM OD SPRING)	85-87	500-066	NONE
BMW	R65G/S (26.5MM OD SPRING)	upto 87	500-084	
BMW	R65 Single sided arm	85on	500-097	
BMW	R65RT Single sided arm	85on	500-196	
BMW	K75/C/S/T/LR/RT	83-91	500-086	NONE
BMW	K75/A/S/RT	92-95	500-065	
BMW	R75/5/6/7	upto 87	500-084	60MM X 26
BMW	R80/7	upto 87	500-084	60MM X 26
BMW	R80GS	80-88	500-084	NONE
BMW	R80RT	85-87	500-066	NONE
BMW	R80RT Single sided arm	85on	500-196	
BMW	R85GS (cartridge)	96on	500-114	

<b>BMW</b>	R80GS P.D. HART	88on	500-087	
<b>BMW</b>	R80GS PARALEVER/ST. TANK	88on	500-085	
<b>BMW</b>	R80R	92on	500-065	
<b>BMW</b>	R80ST	83on	500-104	
<b>BMW</b>	R90/6	upto 87	500-084	60MM X 26
<b>BMW</b>	K-1 CARTRIDGE(30.5MM OD SPR)	91on	500-143	
<b>BMW</b>	K-1 (34MM OD SPRING)		500-086	NONE
<b>BMW</b>	K-1	89-90	500-144	
<b>BMW</b>	R100/CS/RS/RT	upto 87	500-084	60MM X 26
<b>BMW</b>	R100GS	88-96	500-087	NONE
<b>BMW</b>	R100GS CARTRIDGE	96on	500-114	
<b>BMW</b>	R100GS P.D.HART	88-96	500-087	
<b>BMW</b>	R100GS PARALEVER/ST. TANK	88on	500-085	
<b>BMW</b>	R100R	91-96	500-065	
<b>BMW</b>	R100RS/RT	85-96	500-196	NONE
<b>BMW</b>	R100RT		500-196	NONE
<b>BMW</b>	K100/LT/RS/RT	83-99	500-003	NONE
<b>BMW</b>	K100RS 16V	90on	500-142	
<b>BMW</b>	K1100LT	92on	500-143	
<b>BMW</b>	K1100RS	92on	500-143	
	<b>BUELL</b>			
<b>BUELL</b>	M2 CYCLONE	97-98	500-222	
	<b>CAGIVA</b>			
<b>CAGIVA</b>	650 ALAZURA	83 on	500-083	
<b>CAGIVA</b>	650 RAPTOR	00 on	500-273	
<b>CAGIVA</b>	750 LUCKY	93on	500-117	
<b>CAGIVA</b>	750AC ELEFANT	94on	500-117	
<b>CAGIVA</b>	900 IE LUCKY (Single Spring)	90-91	500-124	
<b>CAGIVA</b>	900 LUCKY	93on	500-117	
<b>CAGIVA</b>	900 ELEFANT (USD)	93-95	500-072	
<b>CAGIVA</b>	900 ELEFANT AC (USD) SHOWA	95on	500-168	
<b>CAGIVA</b>	1000 RAPTOR	00 on	500-273	
	<b>CAN-AM</b>			
<b>CAN-AM</b>	ALL MODELS W/40MM FORKS		500-085	270MM X 33
<b>CAN-AM</b>	ALL MODELS W/42MM FORKS		500-099	237MM X 35
	<b>DUCATI</b>			
<b>DUCATI</b>	400 SS SHOWA	91-94	500-088	
<b>DUCATI</b>	500/600 PANTHER	78-86	500-212	
<b>DUCATI</b>	Monster 600 (SHOWA/MARZ. UPSD)	94-99	500-021	
<b>DUCATI</b>	600SS (MARZ. UPSD)	94on	501-004	
<b>DUCATI</b>	650 PANTHER	78-86	500-212	
<b>DUCATI</b>	748/SP (SHOWA UPSD)	94on	500-009	
<b>DUCATI</b>	750	75-85	500-151	
<b>DUCATI</b>	750 FI/B	86-89	500-038	
<b>DUCATI</b>	750GT/S	72-77	500-015	100MM X 30
<b>DUCATI</b>	M750 (MARZ.UPSD)	97on	500-021	
<b>DUCATI</b>	M750 (SHOWA)	95-96	500-088	
<b>DUCATI</b>	750SS (SHOWA UPSD)	91-94	500-088	

<b>DUCATI</b>	750SS (MARZ.UPSD)	95on	501-004	
<b>DUCATI</b>	851 STRADA (MARZ.M1R)	88-89	500-149	
<b>DUCATI</b>	851 STRADA (Showa)	91 on	500-005	
<b>DUCATI</b>	860GT	75-77	500-015	100MM X 30
<b>DUCATI</b>	888 STRADA / SP5 (Showa)	93 on	500-005	
<b>DUCATI</b>	900 all models	75-85	500-151	
<b>DUCATI</b>	900SS/GTS	77-79	500-015	100MM X 30
<b>DUCATI</b>	M900 (SHOWA UPSD)	93on	500-088	
<b>DUCATI</b>	M900 (MARZ.UPSD)	97on	500-108	
<b>DUCATI</b>	900SS (MARZ)	89-90	500-082	
<b>DUCATI</b>	900SS (SHOWA UPSD)	91-95	500-005	
<b>DUCATI</b>	900SS	96on	500-088	
<b>DUCATI</b>	900 Monster (Showa forks)		500-047	Re-use original spacer.
<b>DUCATI</b>	916 STRADA/BIPO (SHOWAUPSD)	94on	500-009	
<b>DUCATI</b>	1000	75-85	500-151	
	<b>EGLI</b>			
<b>EGLI</b>	35MM		500-008	
<b>EGLI</b>	38MM		500-149	
	<b>FORCELLA</b>			
<b>FORCELLA</b>	38MM		500-195	
<b>FORCELLA</b>	40MM		500-082	
<b>FORCELLA</b>	42MM		500-186	
	<b>GILERA</b>			
<b>GILERA</b>	NORDWEST 600	91on	500-132	
<b>GILERA</b>	RC600	89-90	500-087	
<b>GILERA</b>	SATURNO - EUROPE	89 on	500-232	