

MAKE	MODEL	YEAR	IKON Nr	SPACER /COMMENT
TRIUMPH	T120	70-72	500-091	14MM X 27
TRIUMPH	T140	73-83	500-091	14MM X 27
TRIUMPH	TR120	72-73	500-091	14MM X 27
TRIUMPH	TR6	71-72	500-091	14MM X 27
TRIUMPH	T160		500-211	37mm x 27mm spacer
TRIUMPH	T509/595	97on	500-057	
TRIUMPH	BONNEVILLE (NEW)	01-05	500-106	12MM X 34 Shorten original spacer. OEM nr T2047110
TRIUMPH	BONNEVILLE AMERICA	02	500-027	can also use 500-102, in both cases shorten original spacer to suit
TRIUMPH	TRIDENT 750	92on	500-121	
TRIUMPH	DAYTONA 900	91on	500-128	
TRIUMPH	DAYTONA SUPER 111	94on	500-128	
TRIUMPH	DAYTONA SPEED TRIPLE	94on	500-128	
TRIUMPH	ROCKET III	04 on	500-259	
TRIUMPH	Scrambler	05-06	500-106	Shorten original spacer to suit.
TRIUMPH	Speed Triple T 509, 955i	97-04	500-057	
TRIUMPH	Speed Triple 1050 - 515NJ	05 on	500-009	
TRIUMPH	900 SPRINT	95on	500-187	
TRIUMPH				
TRIUMPH				
TRIUMPH	THUNDERBIRD	95on	500-186	
TRIUMPH	THRUXTON	04 on	500-113	Shorten original spacer to suit. Suggested length is 35mm. OEM nr T2049022
TRIUMPH	TIGER T400	93-98	500-046	
TRIUMPH	TIGER T709T	99-01	500-230	
TRIUMPH	TIGER 955i 709EN/795	01-04		
TRIUMPH	TIGER 955i 709EN	05	500-037	Shorten original spacer to suit
TRIUMPH	TRIDENT 900	92on	500-121	
TRIUMPH	TROPHY 900	92on	500-187 500-128	When using 500-128 a 37 x 60mm spacer is required
TRIUMPH	DAYTONA 1200	91on	500-128	
TRIUMPH	TROPHY1200	92on	500-187	