

| FORK SPRING APPLICATION LIST | | | | |
|-------------------------------------|---------------------------|-------------|---------------------------------|---|
| MAKE | MODEL | YEAR | IKON Nr | SPACER /COMMENT |
| BMW | R45 | 78-85 | 500-140 | |
| BMW | R50/5 | upto 87 | 500-084 | |
| BMW | R60, R60/5 | upto 87 | 500-084 | |
| BMW | F650 | 94-00 | 500-141, 500-121, 500-013 | 250MM X 34, |
| BMW | F650GS | 00 on | 500-141 | |
| BMW | F650GS Dakar | 00 on | 500-255, 500-086 | 150mm standard factory spacer. Reduce by 55mm when using 500-086. |
| BMW | F650CS | 02 on | 500-282 | |
| BMW | F800S | 06 on | | |
| BMW | R65 | 78-84 | 500-140 | NONE, Can also use 500-083 with 15mm spacer. 500-083 good for heavier duty use. |
| BMW | R65LS | 78-85 | 500-140 | |
| BMW | R65 (30MM OD SPRING) | 85-87 | 500-066 | NONE |
| BMW | R65G/S (26.5MM OD SPRING) | upto 87 | 500-084 | |
| BMW | R65 Single sided arm | 85on | 500-097 | |
| BMW | R65RT Single sided arm | 85on | 500-196 | |
| BMW | K75/C/S/T/LR/RT | 83-91 | 500-086 | NONE |
| BMW | K75/A/S/RT | 92-95 | 500-065 | Can also use 500-101 + 20mm x 32mm spacer OR 500-025 with a 95mm spacer |
| BMW | R75/5/6/7 | upto 87 | 500-084 | 60mm X 26mm, Extra heavy duty use 500-161 with 90mm x 26mm spacer |
| BMW | R80/7 | upto 87 | 500-084 | 60mm X 26mm, Extra heavy duty use 500-161 with 90mm x 26mm spacer |
| BMW | R80GS | 80-88 | 500-084 | NONE |
| BMW | R80RT | 85-87 | 500-066 | NONE |
| BMW | R80RT Single sided arm | 85on | 500-196 | NONE |
| BMW | R85GS (cartridge) | 96on | 500-114 | |
| BMW | R80GS P.D. HART | 88on | 500-087 | |

| | | | | |
|------------|------------------------------|---------|---------|---|
| BMW | R80GS PARALEVER/ST. TANK | 88on | 500-085 | |
| BMW | R80R | 92on | 500-065 | |
| BMW | R80ST | 83on | 500-140 | |
| BMW | R90/6 | upto 87 | 500-084 | 60mm X 26mm, Extra heavy duty use 500-161 with 90mm x 26mm spacer |
| BMW | K-1 CARTRIDGE(30.5MM OD SPR) | 91on | 500-143 | |
| BMW | K-1 (34MM OD SPRING) | | 500-086 | NONE |
| BMW | K-1 | 89-90 | 500-144 | |
| BMW | R100/CS/RS/RT | upto 87 | 500-084 | 60mm X 26mm, Extra heavy duty use 500-161 with 90mm x 26mm spacer |
| BMW | R100GS | 88-96 | 500-087 | NONE |
| BMW | R100GS CARTRIDGE | 96on | 500-114 | |
| BMW | R100GS P.D.HART | 88-96 | 500-087 | |
| BMW | R100GS PARALEVER/ST. TANK | 88on | 500-085 | |
| BMW | R100R | 91-96 | 500-065 | |
| BMW | R100RS/RT | 85-96 | 500-196 | NONE |
| BMW | R100RT | 94-95 | 500-196 | NONE |
| BMW | K100/LT/RS/RT | 83-99 | 500-003 | NONE |
| BMW | K100RS 16V | 90on | 500-142 | |
| BMW | K1100LT | 92on | 500-143 | |
| BMW | K1100RS | 92on | 500-143 | |