

FORK SPRING APPLICATION LIST				
MAKE	MODEL	YEAR	IKON Nr	SPACER /COMMENT
DUCATI	400 SS SHOWA	91-94	500-088	
DUCATI	500/600 PANTHER - PANTAH	78-86	500-212	
DUCATI	Monster 600 (SHOWA/MARZ. UPSD)	94-99	500-021	
DUCATI	600SS (MARZ. UPSD)	94on	501-004	
DUCATI	650 PANTHER	78-86	500-212	
DUCATI	748/SP (SHOWA UPSD)	94on	500-009	
DUCATI	750	75-85	500-151	
DUCATI	750 FI/B	86-89	500-038	
DUCATI	750GT/S	72-77	500-015	100MM X 30
DUCATI	M750 (MARZ.UPSD)	97on	500-021	
DUCATI	M750 (SHOWA)	95-96	500-088	
DUCATI	750SS (SHOWA UPSD)	91-94	500-088	
DUCATI	750SS (MARZ.UPSD)	95on	500-064	May need 50 to 10mm spacer. Reduce original.
DUCATI	851 STRADA (MARZ.M1R)	88-89	500-149	
DUCATI	851 STRADA (Showa)	91 on	500-005	
DUCATI	860GT	75-77	500-015	100MM X 30
DUCATI	888 STRADA / SP5 (Showa)	93 on	500-005	
DUCATI	900 all models	75-85	500-151	
DUCATI	900SS/GTS	77-79	500-015	100MM X 30
DUCATI	M900 (SHOWA UPSD)	93on	500-088	
DUCATI	M900 (MARZ.UPSD)	97on	500-108	
DUCATI	900SS (MARZ)	89-90	500-082	
DUCATI	900SS (SHOWA UPSD)	91-95	500-005	
DUCATI	900SS	96on	500-088	
DUCATI	900 Monster (Showa forks)		500-047	Re-use original spacer.
DUCATI	916 STRADA/BIPO (SHOWAUPSD)	94on	500-009	
DUCATI	1000	75-85	500-151	