

FORK SPRING APPLICATION LIST				
MAKE	MODEL	YEAR	IKON Nr	SPACER /COMMENT
HONDA	CR125R	84-89		
HONDA	CR125R	90		
HONDA	CR125	91		
HONDA	NX125	88-90	500-084	25MM X 27
HONDA	TLR200 REFLEX	86-87	500-181	
HONDA	XR200R	82-83		
HONDA	XR200R	84-02	500-221	
HONDA	CB250RS	80-84		
HONDA	CBF250	05 on	500-015	
HONDA	CBR250RR (MC17)		500-196	Shorten original spacer to 15mm. OEM spring 250mm x 30mm with 250mm spacer.
HONDA	250 Rebel	1987	500-105	25mm x 24.7mm spacer.
HONDA	CR250	73		
HONDA	CR250	91		
HONDA	CR250R	83-88		
HONDA	CR250R	89-90		
HONDA	NX250	88-90	500-197	200MM X 31
HONDA	RS250RF	93	500-184	
HONDA	250 Spada		500-066	Original 200mm spacer can be shortened or deleted.
HONDA	VTR250	88-90	500-161	USE STD
HONDA	XL250	84-87	500-084	100MM X 27
HONDA	XR250L	91-97	500-099	50MM X 35
HONDA	XR250R	84-85	500-197	
HONDA	XR250R	86-89	500-099	NONE
HONDA	XR250R	90-95		
HONDA	XL350R	84-85		
HONDA	XL350R	85on	500-198	
HONDA	XR350R	83-85	500-099	NONE

HONDA	CB-1 400	89on	500-012	NONE
HONDA	CB400N	78on	500-181	
HONDA	CBR400RR	89-91	500-031	
HONDA	CBR400RR	92on	500-201	
HONDA	NS400R	85on	500-066	
HONDA	VF400FD	83on	500-212	
HONDA	VFR400R	91on	500-021	Original spacer 150mm
HONDA	XR400R		500-204	
HONDA	XR400R		500-204	
HONDA	CB450N/S	85on	500-172	
HONDA	CR480		500-043	
HONDA	500 INTERSEPTOR		500-066	
HONDA	CB500	93-95	500-066	
HONDA	CB500	96on	500-066	
HONDA	CB500F	75on	500-056	
HONDA	CX500	78-82		
HONDA	CX500	81-82	500-095	
HONDA	CX500 Shadow, some models may have earlier forks so need this spring. Check original springs before ordering.	82	500-096	Original spring may be 535mm long, if so a 25 x 21mm spacer is required
HONDA	CX500B	79-80	500-096	
HONDA	CX500 CUSTOM/CX500C	80on	500-069	NONE
HONDA	CX500E	83on	500-192	
HONDA	CX500 CUSTOM		500-061	NONE
HONDA	CX500 TURBO		500-182	NONE
HONDA	CX500 TURBO	83on	500-200	
HONDA	FT500		500-007	USE STD
HONDA	GB500	89on	500-199, 500-212	For 500-199 re-use original spacer, for 500-212 shorten original spacer.
HONDA	GL500	81on	500-083	75MM X 25
HONDA	V30 MAGNA/VF500 F/F2	84on	500-173	USE STD

HONDA	VT500C/E	83on	500-200	USE STD
HONDA	XBR500	85on	500-008	
HONDA	XL500/S	79on	500-220	NONE
HONDA	XR500		500-220	NONE
HONDA	XR500R			
HONDA	XR500R			
HONDA	CR500R			
HONDA	CB550F/K	76-78	500-083	NONE
HONDA	550 NIGHTHAWK/CBX550	82on	500-157	USE STD
HONDA	CB600 HORNET	98on	500-055	
HONDA	CBR600 HURRICANE/CBR600F	87-90	500-173	USE STD
HONDA	CBR600F	91-92	500-010	USE STD
HONDA	CBR600F	93-98	500-202, 500-060	NONE
HONDA	VT600C	88-04	500-173	Shorten original to 30mm
HONDA	XL600R	83-84	501-166	
HONDA	XL600LM/RM	85on	500-160	
HONDA	XL600 TRANSALP	87on	500-124	
HONDA	XR600R	85-90	500-165	NONE
HONDA	XR600R	91on	500-158	NONE
HONDA	CB650		500-061	NONE
HONDA	CB650C		500-061	USE STD
HONDA	CB650B	81on	500-061	
HONDA	650 NIGHTHAWK / CB650SC	81on	500-008	30MM X 27
HONDA	650 NIGHTHAWK / CBX650E	83on	500-035	USE STD
HONDA	CX650C	83on	500-123 500-094	500-094 requires a 24mm x 29mm spacer
HONDA	CX650 TURBO and EURO		500-182	No spacer for Turbo, 20mm spacer for Euro.
HONDA	CX650 TURBO	83on	500-200	
HONDA	GL650		500-182	NONE
HONDA	GL650	82	500-083	

HONDA	GL650 (DU=38MM)	83	500-097	
HONDA	HAWKGT650 / NT650HAWK/BROS	88on	500-011	USE STD
HONDA	NTV650/REVERE	88on	500-012	
HONDA	NX650 / NX650 DOMINATOR	88on	500-103	NONE
HONDA	SLR650	96on	500-090	
HONDA	XL650V Transalp		500-160	
HONDA	XR650L	93-04	500-120	10mm spacer required
HONDA	XR650R	00-04		
HONDA	XRV650 AFRICA TWIN	88-92	500-076	
HONDA	VF700F	83	500-035	
HONDA	VT700C	85<	500-006	
HONDA	VT700C (US)	86on	500-035	
HONDA	700 INTERCEPTOR		500-143	USE STD
HONDA	700 NIGHTHAWK		500-015	122.5MM X 30
HONDA	700 SHADOW		500-035	USE STD
HONDA	VF700C MAGNA		500-008	USE STD
HONDA	VF700C MAGNA		500-035	USE STD
HONDA	VF700C MAGNA		500-196	USE STD
HONDA	VF700S SABRE		500-008	USE STD
HONDA	VFR700 INTERCEPTOR		500-196	USE STD
HONDA	750 INTERCEPTOR		500-143	USE STD
HONDA	750 SHADOW		500-035	USE STD
HONDA	750 SHADOW ACE	98-06	500-011	Shorten original to 30mm
HONDA	750 SHADOW SPIRIT	01-06	500-011	Shorten original spacer to suit
HONDA	CB750 NIGHTHAWK		500-084	USE STD
HONDA	CB750 NIGHTHAWK/CB SEVEN FI	92-03	500-028	No spacer needed or shorten OE
HONDA	CB750A/C	76-82	500-083	USE STD
HONDA	CB750F	75-80	500-083	32.5MM X 25
HONDA	CB750F (25MM OD SPRING)	81on	500-161	
HONDA	CB750F (28MM OD SPRING)		500-008	USE STD

HONDA	CB750K	69-82	500-083	32.5MM X 25
HONDA	CBX750F	84on	500-159	
HONDA	V45 MAGNA/SABRE (750)	82-83	500-172	USE STD
HONDA	VF750C MAGNA		500-196	USE STD
HONDA	VF750C MAGNA DELUXE/VF750C	93-03	500-121	USE STD
HONDA	VFR750 INTERCEPTOR	86-87	500-098	USE STD
HONDA	VFR750 F	88-89	500-013	
HONDA	VFR750 F	90-91	500-027	
HONDA	VFR750 F	92-93	500-026	
HONDA	VFR750 F	94-97	500-026	
HONDA	VFR750R	88-89	500-175	
HONDA	VT750C and Black Widow	97-06	500-170 500-086 500-106	50mm x 34mm spacers with 500-086, 500-106 is for extra heavy duty use and needs a 65mm spacer
HONDA	VT750 ACE with 32mm OD fork springs	03	500-035 500-065	
HONDA	XLV750R (+30MM HULSE)	83-85	500-076	
HONDA	XRV750 AFRICAN TWIN	88-92	500-076	
HONDA	XRV750 AFRICAN TWIN	93-01	500-076	
HONDA	800 SHADOW		500-035	USE STD
HONDA	VFR800F 1 RC46	98-01	500-133	
HONDA	VFR800F RC46	02 on	500-222	
HONDA	PC800 PACIFIC COAST	89-98	500-027	NONE
HONDA	CB900C	80-82	500-182	50MM X 28
HONDA	CB900F Bol d'Or, 39mm forks	80-82	500-143	NONE - Check spring diameter.
HONDA	CB900FA (DU=35MM) Bol d'Or	80	500-176, or 500-	With 500-061 use 35mm spacer.
HONDA	CB900FB (DU=37MM) Bol d'Or	81	500-145	
HONDA	CB900FC (DU=39MM) Bol d'Or	82	500-104	
HONDA	CB900F 919cc engine	02-04	500-051	Shorten OE to 45mm
HONDA	CB900 Hornet	02 on		

HONDA	CBR900RR SC28	92-93		
HONDA	CBR900RR SC28/SC33	94-99	500-057	USE STD, may also use 500-119 and shorten spacer
HONDA	CBR900RR SC44 upside down forks	00-01		
HONDA	CBR900RR SC50 upside down forks	02 on		
HONDA	CB1000/S/F	92on	500-051	USE STD
HONDA	CB1000C		500-143	USE STD
HONDA	CBR1000 HURRICANE/CBR1000F	87-88	500-121	NONE
HONDA	CBR1000F	89on	500-113	USE STD
HONDA	CBX1000	79on	500-162	12.5MM X 25
HONDA	CBX1000	81on	500-163	NONE
HONDA	GL1000	75-76	500-182	DISC STD
HONDA	VF1000/R / VF1000F/R/FII SC15, SC16	84on	500-170, 500-106	NO Spacer required with 500-170, shorten original spacer when using 500-106. 500-106 is a heavier duty option.
HONDA	VTR 1000F FIRESTORM SC36	97on	500-055	
HONDA	1100 SHADOW	85-86	500-011	Shorten OE spacer if required
HONDA	1100 SHADOW/ACE/SPIRIT, C2 SC18, SC23, SC24	87-06	500-011	Shorten OE spacer if required
HONDA	CB1100F	83on	500-143	NONE
HONDA	CB1100R (HALBVERKL)	82	500-008	
HONDA	CB1100RC	80	500-207	
HONDA	CB1100RD (METALLIC)	83	500-065	
HONDA	CBR1100XX BLACKBIRD	97on	500-045	
HONDA	GL1100 GOLDWING	81on	500-143	
HONDA	ST1100 (not ABS models)	90-02	500-147	This particular bike has two different fork legs. The left fork leg requires the stock fork spacer to be shortened to approx 83mm. The right fork leg requires the stock spacer to be removed and discarded. No spacer is needed in the right fork leg.
HONDA	ST1100 ABS	92-95	500-147	Spacer length must be calculated according to the instructions included with the fork springs.
HONDA	ST1100 PAN EURO (O.ABS)	91on	500-146	
HONDA	ST1100 PAN EURO (M ABS/TCS)	91on	500-147	

HONDA	V65 MAGNA / VF1100C	83on	500-093	USE STD
HONDA	V65 MAGNA		500-003	140MM X 34
HONDA	VT1100C (US)	87on	500-085	
HONDA	VT1100C2	93on	500-206	
HONDA	VT1100 AERO, ACE, SABRE, SHADOW, SPIRIT	98-06	500-003	Shorten OE spacer to 75mm
HONDA	GL1200 GOLDWING	84-87	500-106	USE STD
HONDA	CB1300 SC40	98-03		
HONDA	VTX1300S	03-08	500-027	Shorten original spacer
HONDA	GL1500 GOLDWING	88-00	500-106	
HONDA	GL1500C/D/T VALKYRIE / TOUR	97-03		
HONDA	GL1500 VALKYRIE Interstate	99-01		
HONDA	GL1800 Goldwing	01-08	500-051	Shorten original spacer by 45mm
HONDA	VTX1800, C,F,N,R,S,T	02-08	500-001	