

| <b>FORK SPRING APPLICATION LIST</b> |   |             |                |  |
|-------------------------------------|---|-------------|----------------|--|
| <b>MAKE</b>                         | <b>MODEL</b>  | <b>YEAR</b> | <b>IKON Nr</b> | <b>SPACER /COMMENT</b>                                     |
| TRIUMPH                             | T120  | 70-72       | 500-091        | 14MM X 27  |
| TRIUMPH                             | T140  | 73-83       | 500-091        | 14MM X 27  |
| TRIUMPH                             | TR120   | 72-73       | 500-091        | 14MM X 27  |
| TRIUMPH                             | TR6   | 71-72       | 500-091        | 14MM X 27  |
| TRIUMPH                             | T160  |             | 500-211        | 37mm x 27mm spacer   |
| TRIUMPH                             | T509/595  | 97on        | 500-057        |  |
| TRIUMPH                             | Adventrurer   |             |                |  |
| TRIUMPH                             | BONNEVILLE (NEW)  | 01-09       | 500-106        | 12MM X 34 Shorten original spacer.                         |
| TRIUMPH                             | BONNEVILLE AMERICA  | 02-09       | 500-027        | The original spacer should be cut to 150mm - 155mm.        |
| TRIUMPH                             | TRIDENT 750   | 92on        | 500-121        |  |
| TRIUMPH                             | DAYTONA 900   | 91on        | 500-128        |  |
| TRIUMPH                             | DAYTONA SUPER 111   | 94on        | 500-128        |  |
| TRIUMPH                             | DAYTONA SPEED TRIPLE  | 94on        | 500-128        |  |
| TRIUMPH                             | ROCKET III  | 04-09       | 500-259        |  |
| TRIUMPH                             | Scrambler   | 05-09       | 500-106        | Shorten original spacer.                                   |
| TRIUMPH                             | Speed Triple T 509, 955i  | 97-04       | 500-057        |  |
| TRIUMPH                             | Speed Triple 1050 - 515NJ   | 05 on       | 500-009        |  |
| TRIUMPH                             | 900 SPRINT  | 95on        | 500-187        |  |
| TRIUMPH                             |   |             |                |  |
| TRIUMPH                             |   |             |                |  |
| TRIUMPH                             | THUNDERBIRD, T309RT   | 95on        | 500-186        |  |
| TRIUMPH                             | THUNDERBIRD Sport, with adjustable rebound damping. T309RT, RD309 | 97 on       | 500-054        |  |
| TRIUMPH                             | THRUXTON  | 04-09       | 500-113        | Shorten original spacer to suit. Suggested length is 35mm. |
| TRIUMPH                             | TIGER T400  | 93-98       | 500-046        |  |
| TRIUMPH                             | TIGER T709T   | 99-01       | 500-230        |  |
| TRIUMPH                             | TIGER 955i 709EN/795  | 01-04       |                |  |

|                |                    |       |                    |   |
|----------------|--------------------|-------|--------------------|---|
| <b>TRIUMPH</b> | TIGER 955i 709EN   | 05-06 | 500-037            | Shorten original spacer (185mm) to suit.          |
| <b>TRIUMPH</b> | TIGER 1050 (115NG) | 07    | 500-089            |   |
| <b>TRIUMPH</b> | TRIDENT 900        | 92on  | 500-121            |   |
| <b>TRIUMPH</b> | TROPHY 900         | 92on  | 500-187<br>500-128 | When using 500-128 a 37 x 60mm spacer is required |
| <b>TRIUMPH</b> | DAYTONA 1200       | 91on  | 500-128            |   |
| <b>TRIUMPH</b> | TROPHY1200         | 92on  | 500-187            |   |