

MAKE	MODEL	YEAR	IKON Nr	SPACER /COMMENT
KAWASAKI	KX125	83-87		
KAWASAKI	KX125	90		
KAWASAKI	KX125	91-92	500-080	NONE
KAWASAKI	KDX200	83-85	500-197	250MM X 31
KAWASAKI	KDX200	86-92		
KAWASAKI	KDX200	93-94		
KAWASAKI	KDX200	95-97		
KAWASAKI	250 NINJA	86-87	500-091	14MM X 27
KAWASAKI	250 NINJA	88-04	500-008	Shorten original spacer
KAWASAKI	EL250	91on	500-180	
KAWASAKI	GPX250	96	500-015 500-066	500-015 requires a 75mm x 30mm spacer, 500-066 for extra heavy duty use
KAWASAKI	KLR250 / KLR250R	84-04	500-221	NONE
KAWASAKI	KLX250	79-80	500-221	250MM X 29
KAWASAKI	KLX250	94-96	500-204	
KAWASAKI	KLX250	99-07		
KAWASAKI	KX250	82-87		
KAWASAKI	KX250	90		
KAWASAKI	KX250	91-92	500-080	NONE
KAWASAKI	KLX300	97-04		
KAWASAKI	KLX400 R/SR	03		
KAWASAKI	ZXR400 (UPSD 41MM)	91on	500-088	
KAWASAKI	EX500	87-93	500-008	None
KAWASAKI	EX500	94-04	500-008	None with 008, may also use 500-040 for heavier duty purposes. A 20mm spacer is needed with 040 by shortening the OE one.
KAWASAKI	ER5	96-00	500-077	
KAWASAKI	KLE500	91on	500-116	
KAWASAKI	GPZ500S A1 - A6	87-93	500-008	
KAWASAKI	GPZ500S	94-96	500-015	
KAWASAKI	KX500	83-84		
KAWASAKI	KX500	85-88		
KAWASAKI	KX500	90		
KAWASAKI	KX500	91-92	500-080	NONE
KAWASAKI	550 ZEPHYR	90-91	500-196	USE STD
KAWASAKI	550 ZEPHYR	92on	500-014	

KAWASAKI	GPZ550	81-86	500-161	
KAWASAKI	GPZ550	81-86	500-161	
KAWASAKI	KZ550LTD/SPECTRE	80-83	500-083	250MM X 25
KAWASAKI	Z550F	83on	500-203	
KAWASAKI	KZ550A	80-83	500-083	250MM X 25
KAWASAKI	600 NINJA / GPZ600R	85on	500-097	NONE
KAWASAKI	600 NINJA / GPX600R	88on	500-097	DISC STD
KAWASAKI	KLR600/E	84on	500-148	
KAWASAKI	ZL600	85-87	500-127	DISC STD
KAWASAKI	ZX-6-D	90-93	500-003	NONE
KAWASAKI	ZX6R RACING	95-97	500-067	
KAWASAKI	ZX6R RACING (8.5 N/MM)	98-99	501-074	
KAWASAKI	ZX6R RACING (9 N/MM)	98-99	501-137	
KAWASAKI	ZX6R RACING (9.5 N/MM)	98-99	501-138	
KAWASAKI	ZX6R STRASSE - NINJA	98-99	500-139	
KAWASAKI	ZX6R	00-01	500-119	
KAWASAKI	ZZR600	90-92	500-019	
KAWASAKI	ZZR600	93on	500-018	
KAWASAKI	CSR650	82-83	500-083	250MM X 25
KAWASAKI	KLR650	87-94	500-148	
KAWASAKI	KLR650 TENGAI	87-94	500-148	
KAWASAKI	KLR650/TEN	95on	500-110	
KAWASAKI	KLX650C	92-96	500-150	
KAWASAKI	KLX650R	92-96	500-150	
KAWASAKI	KZ650	77-83	500-083	NONE
KAWASAKI	W650	99-01	500-066	NONE - remove OE 110mm spacer
KAWASAKI	Z650B	81	500-161	
KAWASAKI	KZ650SR	78-79	500-083	250MM X 25
KAWASAKI	750 NINJA / GPX750R (F1-F3)	87-91	500-196	USE STD
KAWASAKI	750 TURBO /GPZ750T	83on	500-185	17MM X 27
KAWASAKI	750 ZEPHYR	91on	500-003	USE STD
KAWASAKI	GPZ750		500-083	32.5MM X 25
KAWASAKI	GPZ750 / GPZ750ZX (UT)	83on	500-083	18MM X 25
KAWASAKI	GPZ750R	84-86	500-127	
KAWASAKI	KZ750 (TWO CYLINDER)		500-083	100MM X 25

KAWASAKI	Z750B (TWO CYLINDER)	83on	500-178	
KAWASAKI	KZ750E/H / Z750	80-83	500-083	100MM X 25
KAWASAKI	Z750	83on	500-083	
KAWASAKI	Z750LTD	80on	500-115	
KAWASAKI	VN750 VULCAN		500-008	Re-use original
KAWASAKI	VN750	91-92	500-008	USE STD
KAWASAKI	VN750	93-04	500-008	USE STD
KAWASAKI	ZX-7 NINJA / ZXR750	89-90	500-128	NONE
KAWASAKI	ZXR750 (UPSD 43MM)	91-92	500-017	
KAWASAKI	ZXR750 (UPSD 41MM)	93on	500-016	
KAWASAKI	ZXR750R (UPSD 41MM)	91-94	500-016	
KAWASAKI	ZX7R NINJA	96on	500-034	
KAWASAKI	ZX7RR NINJA	96on	500-017	
KAWASAKI	ZX7RR RACING	96on	501-210	
KAWASAKI	VN800 Vulcan Classic/Drifter	95-05	500-106	37 x 34mm
KAWASAKI	900 NINJA, ZX900A, GPZ900R	84-86	500-185	100MM X 27
KAWASAKI	KZ900/LTD	74-75	500-061	NONE
KAWASAKI	ZL900 ELIMINATOR	85on	500-123	NONE
KAWASAKI	GPZ900RZ (D=38MM)	84-86	500-094	
KAWASAKI	GPZ900RZ (D=38MM)	87-89	500-094	
KAWASAKI	GPZ900R (D=41MM)	90on	500-011	
KAWASAKI	ZX9R NINJA	94-97	500-030	
KAWASAKI	ZX9R NINJA	98on	500-139	
KAWASAKI	Z1R	78-80	500-061	NONE
KAWASAKI	1000 NINJA	86-87	500-196	20MM X 30
KAWASAKI	KZ1000	77-82	500-061	NONE
KAWASAKI	1000 LTD	77-80	500-061	NONE
KAWASAKI	KZ1000 CSR/LTD	81-82	500-008	65MM X 28
KAWASAKI	KZ1000J/R	81-83	500-008	15MM X 28
KAWASAKI	KZ1000ST	79-81	500-015	200MM X 30
KAWASAKI	Z1000A1	78on	500-083	
KAWASAKI	Z1000A2	78on	500-061	
KAWASAKI	Z1000 MK2	79on	500-061	
KAWASAKI	ZG1000 CONCOURS			
KAWASAKI	ZG1000 CONCOURS			

KAWASAKI	ZL1000 ELIMINATOR	87	500-185	30MM X 27
KAWASAKI	ZX-10 NINJA	88-90	500-102	NONE
KAWASAKI	GTR1000	86on	500-101	
KAWASAKI	GPZ1000RX	86-89	500-049	
KAWASAKI	GPZ1100	82	500-008	NONE
KAWASAKI	GPZ1100	83	500-200	100MM X 29
KAWASAKI	KZ1100 (SHAFT) / Z1100 SPECTRE	81-83	500-205 / 500-008	NONE, If using 500-008 a spacer will be required of up to 75mm.
KAWASAKI	GPZ1100	95on	500-039	
KAWASAKI	ZN1100 LTD	84-85	500-008	80MM X 28
KAWASAKI	ZR1100 / 1100 ZEPHYR	92-97	500-063	NONE
KAWASAKI	ZX-11-C / ZZR1100 (C1-3)	90-92	500-071	NONE
KAWASAKI	ZX-11-D / ZZR1100 (D1-9)	93-01	500-020	USE STD, For an even more progressive option use 500-051
KAWASAKI	ZRX1100	97- 00	500-169	
KAWASAKI	ZG1200 VOYAGER	86		
KAWASAKI	ZG1200 VOYAGER	87-97		
KAWASAKI	ZRX1200	00 -	500-054	
KAWASAKI	ZX12R	00-	500-256	
KAWASAKI	KZ1300, Z1300	79 - 90	500-143	20MM X 30
KAWASAKI	1300 VOYAGER	83-87		
KAWASAKI	VN1500 VULCAN/SE/L	88on	500-003	USE STD
KAWASAKI	VN1500 VULCAN CLASSIC	96-04	500-003	27MM X 34
KAWASAKI	VN1500 VULCAN NOMAD	98-01	500-102 500-027	70MM X 34 when using 500-102, 85MM x 34 when using 500-027
KAWASAKI	VN1500 FI VULCAN NOMAD	00-04		
KAWASAKI	VN1500 Mean Streak	02-03	500-050 or 500-	Shorten original spacers by approx 25mm.
KAWASAKI	VN1500 VULCAN DRIFTER	99-04	500-147	SHORTEN ORIGINAL SPACER
KAWASAKI	VN1600 Mean Streak	04	500-050 or 500-	Shorten original spacers by approx 25mm.
KAWASAKI	VN1600 Vulcan Classic	03-04	500-051	Re-use original spacer - check spacer length.